

# USER MANUAL

## *EnerPulse 5 (v2.3)*



## *Notice*

---

The material contained in this manual is subject to change without notice. No part of this manual may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying or electronic transmission or other means of reproduction or distribution without prior written consent of EN Technologies Inc.

The drawings, specification and other technical information contained in this manual are the property of EN Technologies Inc. and shall not be copied, reproduced or used in any way, in whole or in part, as the basis of manufacture or sale of similar items without the prior written permission of EN Technologies Inc.

While EN Technologies Inc. puts its best efforts to provide accurate and complete information, there may be errors in the content.

EN Technologies Inc. shall not be liable for any actions taken in reliance Thereon.

Revision Level : 04/MAR/10

Copyright © 2003–2010 EN Technologies Inc. All rights reserved.

Printed in the Republic of Korea.

## ***Contents***

---

<b>Chapter 1. Introduction</b>	
1.1 Manual Outline	<b>1-1</b>
1.2 Warranty	<b>1-1</b>
1.3 EMC/EMI Standards	<b>1-2</b>
1.4 Safety Notice Supplement	<b>1-2</b>
1.5 Safety Symbol	<b>1-3</b>
<b>Chapter 2. General Description</b>	
2.1 Features	<b>2-1</b>
<b>Chapter 3. Specifications</b>	
3.1 Specifications	<b>3-1</b>
3.2 Dimension	<b>3-7</b>
<b>Chapter 4. Installation</b>	
4.1 Requirement	
4.1.1 For the safe operation	<b>4-1</b>
4.1.2 Airflow requirements	<b>4-2</b>
4.2 Connecting	
4.2.1 Rear side connections	<b>4-3</b>
4.2.2 The connection diagram of the Power supply	<b>4-4</b>
4.2.3 The connection for Pulse synchronization.	<b>4-5</b>
<b>Chapter 5. Operation</b>	
5.1 Front Panel	<b>5-1</b>
5.2 Rear Panel	<b>5-3</b>
5.3 Operating Diagram	<b>5-5</b>
5.4 Menu Map	
5.4.1 Setting Main Menu	<b>5-6</b>
5.4.2 Main Menu	<b>5-6</b>
5.5 Operating Parameter	
5.5.1 Process control	<b>5-9</b>
5.5.2 Arc Processing	<b>5-10</b>
5.5.3 Monitoring Data	<b>5-13</b>
5.5.4 Interface Setup	<b>5-15</b>
5.5.5 Communication Set	<b>5-16</b>
5.5.6 System Configuration	<b>5-16</b>
5.5.7 Operation Record Data	<b>5-16</b>
5.5.8 Fault Record Data	<b>5-16</b>
5.6 Interface	
5.6.1 User1 (D-sub 37pin)	<b>5-17</b>
5.6.2 RS-232/485	<b>5-20</b>
<b>Chapter 6. Maintenance</b>	
6.1 Error message or LED status in the front panel	<b>6-1</b>
6.2 General Troubleshooting	<b>6-2</b>

## Chapter 1. Introduction

---

### 1.1 Manual Outline

This manual is designed for those people who will be installing and operating the EN's power unit. It provides the information required to safely install and operating the power unit.

If used properly, the information contained in this manual will not only promote reliable power output performance, but will also encourage a safe operating for all customers.



<Appearance>

### 1.2 Warranty

This product is manufactured under strict quality control and inspection by the engineers at EN Technologies Inc.

EN Technologies Inc.'s warrants to the original purchaser for a period of 12 months from the date of delivery.

During the warranty period, products damaged under the proper usages will be repaired at request of the customers.

Damage caused by improper use or unauthorized modification of the device dose not constitute grounds for a warranty claim.

## *Chapter 1. Introduction*

---

### 1.3 EMC/EMI Standards

This device has been tested for and complies with EMC standard(s):

- \* EN61000-6-2
- \* EN61000-6-4

### 1.4 Safety Notice supplement

This equipment complies with EN/IEC61010-1:2001  
This equipment is **MEASUREMENT CATEGORY II (CAT II)**  
This equipment is **POLLUTION DEGREE 2, INDOOR USE**  
product

## Chapter 1. Introduction

---

### 1.5 Safety symbol



CAUTION



Protective earth ground



Alternating current.



Direct current



ON



OFF



CE label



This **Warning** sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury or death to personnel.



This **Caution** sign denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.



**Note** denotes important information. It calls attention to a procedure, practice, condition or the like, which is essential to highlight.

## *Chapter 2. General Description*

---

### 2.1 Features

#### Superior Arc Management

Arc energy minimization method decreases damages on substrate during the process; resulting excellent thin film coating. Furthermore, process control parameters (arc level, time, etc.) for arc control, providing diverse process recipe for users.

#### High Performance and Reliability

Applied very stable control topology, realizing high-speed and precise output control during excessive status caused by load. Constant voltage, current, and power control is possible by output regulation selection. Applied system protection device through self diagnosis function.

## Chapter 3. Specifications

### 3.1 Specifications

ITEM		CONTENTS	REMARK
ELECTRICAL SPEC.	Input voltage/ current	187VAC to 228VAC, 3-Phase, 4-wire; 50 to 60Hz; leakage current <3.5mA	
		<17Arms; 30A circuit breaker	
		198VAC to 242VAC, 3-Phase, 4-wire; 50 to 60Hz; leakage current <3.5mA	
		<16Arms; 30A circuit breaker	
		342VAC to 418VAC, 3-Phase, 4-wire; 50 to 60Hz; leakage current <3.5mA	
		<9Arms; 15A circuit breaker	
	Output power	5kW	
	Output Accuracy	< $\pm 0.2\%$ (RATING OUTPUT)	
	Efficiency	>90%	
	Power factor	>0.9	
	Output Frequency	20kHz~150kHz	
	Pulse Output	1000V(6.25A)/400(12.5A) at Duty rate 25%	
	Reverse Time	DC mode, 1.5us~7us(Decrease according to Frequency)	See Fig 3-1
	Average Output	800V(6.25A)/400V(12.5A)	
	Max. Peak Voltage	<b>Max. 1700V</b>	
	Operating Range	See Fig 3-2	
	Regulation	Power/Current/Voltage	
	Arc energy	Less than 1mJ/1kW	
	Arc Detection time	Less than 0.4us	
	Arc control	Level, Delay/Pause time, etc See ARC Processing Menu	
	Communication	RS-232, RS-485	
Interface	Host, Remote, Local		
Sag	See Fig 3-3, 3-4		
Analog Interface Scaling	0 ~ 10V(0 ~ MAX. value)		

## Chapter 3. Specifications


---

### 3.1 Specifications

ITEM		CONTENTS	REMARK
PHYSICAL SPEC.	Dimension [mm]	133[H]*483[W]*600[D]	
	Weight	29kg	
	Display	VFD(2line,20characters), Status LED	
ENVIRONMENTAL SPEC.	Operating Temp.	+5°C~40°C(Ambient Temperature)	
	Operating Humidity	5% to 85%	
	Operating Pressure	0 to 6,562ft(2000M) above sea level	
OPTION	Input cable	>3Phase, 6mm <sup>2</sup>	Optional
	Output cable	RG-214	Optional
	Output connector	SO-239(Ampheno)	

## Chapter 3. Specifications


- Reverse Time curve at Operating Frequency.



<Fig 3-1. Reverse Time Curve>


## Chapter 3. Specifications

### ► Operating range




# Chapter 3. Specifications

► Sag test




< Fig 3-3. 30% Input Voltage Drop test, 20kW(400V,50A), 10s >



<Fig 3-4 SEMI F47 SPEC.>


► Output Waveform



< Fig3-5. Pulse waveform >

- \*  $V_{p1}$  : Nominal Pulse Voltage
  - – Adjustable by user
- \*  $V_{p2}$  : Imposed Voltage
  - – Improved ionization and Ignition performance
  - –  $V_{p1} + dV$ ,  $dV = 100 \sim 300V$  (default 100V)
  - – Width depend on chamber condition ( = current rising time ),
  - Not adjustable
- \*  $V_o$  : Average value of  $V_{p1}$

### 3.2 Dimension



<Dimensional drawing>

## Chapter 4. Installation

---

### 4.1 Requirements

#### 4.1.1 For the safe operation

▶ Condition of Use

To meet with the stated directives and standards, you must meet with the following conditions of use.

- This device must be installed according to the installation instruction of the manual
- To make any connection, connect the auxiliary protective earth ground stud on the rear panel.
- Must connect input power cables after checking the rated input power of the device.
- Use only a shield cable on the input power connector and on the output power connector.
- Do not use non-standard connectors for input and/or output power
- If your system does not have a circuit breaker, install and operate it with an approved circuit breaker on the ac input to provide the required over-current protection.

▶ Installation Location

Avoid excessive moisture.

Avoid extremely high temperature places.

Avoid places with frequent vibration.

Avoid dusty places.

Avoid air circulation is interrupted.



▶ Cautions

Use ground stud for your safety.

Use proper voltage.


(Prior to connecting input power, check whether it fits power supply's specifications)

Be cautious about disconnection of input & output cables.

### 4.1.2 Airflow requirements

Coolant each air inlet located on the unit's front panel and front-side panel provide for air intake. Exhausted warm air leaves the unit through coolant air outlets located on the unit's rear panel and rear-side panel

Consideration must be given to the power unit's installation so as not to impede the supply or flow of air to the unit.




<Side clearance for the power unit in a cabinet>



If the space above-mentioned cannot be guaranteed, the power supply may be shut down during operation. Please ensure the ambient temperature should be managed under 40 degrees.

## 4.2 Connecting

### 4.2.1 Rear side connections



<Rear side>

\*Please make sure to follow the connecting turn as below.

- ① Ground connection  
Before making any other connection, connect a ground stud to earth ground. For your safety, use after grounding the power supply. ( Leakage Current : < 3.5mA )
- ② Output power connecting  
The standard output connector is SO-239.
- ③ Input power connection  
Input terminal is made of 3Pin Terminal block.  
The power unit's input voltage is three phase, 50/60Hz. Note that no neutral connection is required.




#### Warning

1. Off the Switch(NFB) on the main Electric panel, and then connect the cable in orders. If not, There would be a electrical shock.
2. Operating and maintenance personnel should be suitably trained before setting up and maintaining high-energy electrical equipment.  
This equipment has to be installed according to applicable requirement.
3. Do not apply RF power directly to the output of the device. It can cause damage to EN power supply. If you use both a RF power and EN power supply in the same system, put a RF filter in the system.

## 4.2 Connecting

## 4.2.2 The connection diagram of the Power supply

## Coating Chamber



## Electric Panel



**Warning**

Before connecting the input cable, be sure to putting down the main switch on the main electric panel , and connect as following sequence 'Ground cable→Output Cable→Input Cable'. The input voltage should be checked before putting the main switch on, and if it is measured more than Max. Input voltage, Do not put the switch(NFB)On the main electric panel.

## 4.2 Connecting

### 4.2.3 The connection for Pulse synchronization.

#### 1. Connecting the master with the slave by the UTP cable( ..Shorter than 50cm)



#### 2. Setting the Process Control (Synchronize EnerPulse) \* change set point of EnerPulse

1. Press Menu key.  
You will see the screen on the right.
2. Press Enter key, use Volume knob to move to Pulse sync.  
( Int ⇒ Ext )

```
Vin: 0, Vp: 0
Ip: 0.0, Po: 0.0
```

```
MENU FUNCTIONS
1. Process Control
```

```
MENU FUNCTIONS
4. System Configura.
```

```
Pulse sync: Int
Pulse Freq: 50kHz
```


```
Pulse sync: Ext
Pulse Freq: 50kHz
```

#### Pulse Synchronization.

- Output frequency synchronization of two or more Enerpulse10
- Other parameters are self-control (Ramping Time, Reverse Time, etc)

# Chapter 5. Operation

## 5.1 Front Panel




**Display** Used for indicating the status of the power.

**LED** Used for efficient monitoring of the output status

- Arc illuminates when an arc occurs
- Limit illuminates when output voltage/power/ current or interior temperature value exceeds than maximum set value
- Fault illuminates when an error occurs on the power supply
- Setpoint illuminates when output reaches to set value
- Interlock illuminates off when the interlock signal occurs(Normal ON)
- Protection illuminates when the over-current or hard arc occurs

Regulation	Used for setting the output regulation mode (Voltage/ Current/ Power)
OP Mode	Used for selecting the user interface
Host	Gives control to the host computer through the serial port
Local	Takes back control from the serial port or user port and give it to the control panel at the front
Remote	Gives control to the controller through the user port. (37Pin D-sub, Refer to 5.6 Interface >
Menu/Enter keys	Used for navigating in menu lists and for setting values
On/Off	Used for turning output power on and off
Modify	Used for navigating in menu lists and setting the required values and parameters

## 5.2 Rear Panel




&lt;Rear panel&gt;

- Dip switch Provides the operator a way to select the master or slave unit and set the slave address of this unit (Not Used)
- Master/Slave  
Used for operating parallel running
- RS-232 Used for operating the serial communications with a host computer
- RS-485 Used for operating the serial communications with a host computer
- User1 This interface lets you use the digital/Analog interface Connector type is D-sub 37p female Currently, User1's interface is customized to customer's request, Please refer to 5.6 Interface.
- User2 Connector type is D-sub 9p female (Not Used)


- Output      The output connector is UHF type (SO-239)  
The center conductor is the output of a negative voltage.  
( Contact to the chamber. )  
The shell conductor is the output of a positive voltage.  
( Contact to the target. )
- Input        This power unit's input voltage is three phase, 50/60Hz.  
The ac input connection is provided by means of a three terminal block.
- Ground      Used for grounding the body of the power unit  
Always use after grounding the power supply for your safety.
- Input switch      Used as the switch for supplying input power to power unit. Circuit protection function is internalized inside the switch.

## 5.3 Operating Diagram.



## 5.4 Menu Map

### 5.4.1 Setting Main Menu



### 5.4.2 Main Menu


Main Menu	Sub Menu	Default
Process Control	Max Power (2.0 ~ 5.0kW)	5kW
	Max Current (5 ~ 12.5A)	12.5A
	Max Voltage (500 ~ 800V)	800V
	Ramp Time (500 ~ 2000ms)	500ms
	Pulse Synchro(Int, Ext.)	Int.
	Pulse Freq(20~150kHz)	50kHz
	Rev Time(OFF:DC, 1.5~7us)	2us
	Target Life(OFF~9999kWh)	OFF
	Run Time Sq(OFF~99:99:99)	OFF

Arc Processing	Delay Time (0 ~ 5us)	0us
	Pause Time (40 ~ 200us)	50us
	Arc Voltage(Disable, 11~100V)	50V
	Increment A (Disable, 5~30A)	10A
	Sensitivity (Disable~6Steps)	Middle
	Limit Arc Number(0~4000/s)	Disable
	Total ARC Number(0~99999)	Disable

## 5.4.2 Main Menu

<u>Main Menu</u>	<u>Sub Menu</u>	<u>Default</u>
Monitoring Data	Cs(Vs,Is,Ps ,Reference)	Enable
	Vp1 (Nominal Pulse Voltage)	Enable
	Ip (Output Pulse current)	Enable
	Po (Output power, W)	Enable
	AN (Arc count, Arc/s)	Disable
	ANT(Total Arc , Arc/1batch)	Disable
	RT(Running time,h:m/1batch)	Disable
	WhR(Total power in Run time)	Disable
	WhT (Accumulated power)	Disable
	Vp2(Imposed Voltage )	Disable
	Vo(Output Average Voltage)	Disable
	Pp(Output Pulse Power)	Disable
	Interface Setup	ON/OFF Master
Reference Master		Origin
Mode Master		Origin
Rate Voltage(1.0~10.0V)		10.0V
Rate Current(1.0~10.0V)		10.0V
Rate Power(1.0~10.0V)		10.0V
Ref. Deadzone(0.3%~20%)		1%
A/Ri Offset(-9.9%~9.9%)		0%
A/Vo Offset(-9.9%~9.9%)		0%
A/Io Offset(-9.9%~9.9%)		0%
A/Po Offset(-9.9%~9.9%)		0%
A/Ro Offset(-9.9%~9.9%)		0%

## 5.4.2 Main Menu



## 5.5 Operating Parameter

### 5.5.1 Process control

<b>Max Power</b>	Sets a limited Max.output power.
<b>Max Current</b>	Sets a limited Max.output current.
<b>Max Voltage</b>	Sets a limited Max.output voltage.
<b>Ramp time</b>	Time to reach up to the setpoint.
<b>Pulse Sychro.</b>	Output frequency synchronization. (Int / Ext)
<b>Pulse Frequency</b>	Sets Output Pulse Frequency.
<b>Reverse Time</b>	Sets a Reverse Time(1.5~8us, Self Limited)
<b>Run Time Sq</b>	Setting the operating time.
<b>Target life</b>	Set the Target life( kWh/Target), see the interface,5–6)

- Using the process control  
(To modify Max current of  
12.5A to 10A)

1. Press Menu key.  
You will see the screen  
on the right.
2. Press Enter key.  
You will see the screen  
on the right.
3. Use Volume knob to move  
to [Max current] item.
4. Press Enter key, then  
cursor will blink. Use  
Volume knob to set  
the desired value. Press Enter key again.

```
Vr: 0,Vo: 0
Io: 0.0,Po: 0.0
```

```
MENU FUNCTIONS
1.Process Control
```

```
Max Power : 5.0kW
Max Current: 12.5A
```

```
MAx Power : 5.0kW
Max Current: 12.5A
```


```
MAx Power : 5.0kW
Max Current: 10.0A
```

- ※ Follow the same steps to control and set other control parameters.

## 5.5.2 Arc Processing

<b>Delay time</b>	Sets to keep the output without interruption when arc detects(0 ~5us)
<b>Pause time</b>	Sets shutdown time until re-start after arc occurrence (40 ~ 200us)
<b>Arc Voltage</b>	Sets Voltage level to detect Arc. (Disable, 11 ~ 100V)
<b>Increment Current</b>	Sets Current level to detect Arc. (Disable, 5A ~ 15A)
<b>Sensitivity</b>	Sets the level to detect soft arc(Micro Arc), control parameter for interruption of soft arc that is relatively more sensitive than Increment Current or arc voltage. (disable/UT-Low/Low/Middle/High/UT-High)
<b>Limit Arc Number</b>	Sets the number of Arc that is restricted per sec. if it exceeds, The message is displayed. The power supply continues to process.
<b>Total Arc Number</b>	Sets the total number of Arc that is required in the full processing. if it exceeds, The message is displayed. The power supply continues to process.


► Parameters for arc control



**Caution**


Arc Energy is changed according to the increment current level, so you should set the appropriate level according to process..

Arc Voltage (Disable, 11~200V)



**Caution**

If it is set under the operating voltage level, Normal process is impossible, so you may set the appropriate voltage according to process.



**Caution**

Arc Energy can be increased from 0.4mJ/kW to Max.30mJ/kW, By reason of this. It can be damaged on the coated material.

- Using the Arc processing  
(To set Pause time of  
40us to 100us)

1. Press Menu key then  
you will see the screen  
on the right.

Vr:				0,	Vo:				0
Io:			0.	0,	Po:			0.	0

2. Use Volume knob to  
move to [2.Arc processing]  
menu.

MENU FUNCTIONS									
1.	Process	Control							

3. Press Enter key, use  
Volume knob to move to  
[Pause time] item.

MENU FUNCTIONS									
2.	Arc	Processing							

4. If you press Enter key,  
cursor will blink. Then  
use Volume knob to set  
to desired value.  
Press Enter key again.

Delay	time	:						0	us
█	Pause	time	:					40	us

Delay	time	:						0	us
█	Pause	time	:					100	us

- ※ Follow the same steps to control and set other  
Control parameters.

### 5.5.3 Monitoring Data

- ▶ This function allows users to select variables displayed at front panel for monitoring power supply's output status. Four is the maximum number of parameters that can be displayed.

Cs	Indicates Control Mode setpoint value.
Vp1	Indicates Output Pulse Voltage
Ip	Indicates Output Pulse Current
Po	Indicates Output Average Power
AN	Indicates Number of Arc occurrence per second
ANT	Indicates Number of the total Arc (total Arc/batch)
RT	Running time
WhR	Indicates the used power during the process.
WhT	Indicates Accumulated Power
Vp2	Indicates the input DC bank Voltage
Vo	Indicates Output Average Voltage
Pp	Indicates Output Pulse Power

- ▶ Using the monitoring data (Modify indicating factors from Vr, Vo, Io, Po to Vr, Vo, Io, AN.)

1. Press Menu key.  
You will see the screen on the right.

```
Vr:      0,Vo:      0
Io:      0.0,Po:    0.0
```

2. Move to [3.Monitoring Data] using Volume knob

```
  MENU FUNCTIONS
1.Process Control
```

3. Press Enter key, use Volume knob to move to [Po] item.

```
  MENU FUNCTIONS
3.Monitoring Data
```

```
SELECT ITEM (0/X) 4
Io:←Vo:←Po:←ArcN:
```

4. Change [Po:o] to [Po:x]  
using Enter key

S	E	L	E	C	T	I	T	E	M	(	0	/	X	)	3				
I	o	:	O	←	V	o	:	O	←	P	o	:	X	←	A	N	:	O	←

5. Press Enter key, move to  
[AN] using Volume knob.

S	E	L	E	C	T	I	T	E	M	(	0	/	X	)	4				
V	o	:	O	←	P	o	:	X	←	A	N	:	O	←	R	T	:	X	←

6. Change [AN:x] to [AN:o]  
using Enter Key

V	r	:								0	,	V	o	:						0	
I	o	:								0	.	0	,	A	N	:					0

7. Then you will see the screen  
on the top-right.

※ Other factors can also show their monitoring variables  
by following the same steps

## 5.5.4 Interface Setup

- ▶ This function is setting menu of interface per user's request.

<b>ON/OFF Master</b>	Set ON/OFF of input interface ( Origin, Local, Remote, Host )
<b>Reference Master</b>	Set Reference of input interface. ( Origin, Local, Remote, Host )
<b>Mode Master</b>	Set Mode of input interface. ( Origin, Local, Remote, Host, Always )
<b>Max. Analog I/O Ref. (Voltage)</b>	Set Max. value of analog input/output (Voltage) ( 1.0 ~10.0V )
<b>Max. Analog I/O Ref. (Current)</b>	Set Max. value of analog input/output (Current) ( 1.0 ~10.0V )
<b>Max. Analog I/O Ref. (Power)</b>	Set Max. value of analog input/output (Power) ( 1.0 ~10.0V )
<b>Reference Deadzone</b>	Ignored reference of less than setting value.(0.3%~20%)
<b>A/Ri Offset</b>	Adjust the Analog Reference Input Offset at USER1 port(-9.9%~9.9%)
<b>A/Vo Offset</b>	Adjust the Analog Voltage Output Offset at USER1 port(-9.9%~9.9%)
<b>A/Io Offset</b>	Adjust the Analog Current Output Offset at USER1 port(-9.9%~9.9%)
<b>A/Po Offset</b>	Adjust the Analog Power Output Offset at USER1 port(-9.9%~9.9%)
<b>A/Ro Offset</b>	Adjust the Analog Reference Output Offset at USER1 port(-9.9%~9.9%)

•For example, even if it is operating by Local Mode, If set by Remote from ON/OFF Master when ON/OFF enables in Remote, ON/OFF is possible in Remote(PLC).

### 5.5.5 Communication Set

- ▶ This menu is about RS232, RS485 and protocol.

<b>Protocol type</b>	Set protocol type. ( 1~5, refer to the attached protocol, Preliminary )
<b>Communication Mode</b>	Set the RS232, RS485. ( RS232, RS485 )
<b>Comm. IP Address</b>	Set address in RS485 communication ( disable, 1~50 )

### 5.5.6 System Configuration

- ▶ Set the parallel operating

<b>Parallel Number</b>	Set the total number of units in parallel operating (Master+Slave) ( Min : 1, Max : 8 ) ※Not Used.
------------------------	--

### 5.5.7 Operation Record Data

- ▶ Display operation record data of unit

<b>Integral Run kWh</b>	.
<b>Average Run watt</b>	.
<b>Power ON Counter</b>	.
<b>Integral Run Hour</b>	.
<b>Total Run kWh</b>	.
<b>Total ON Counter</b>	.
<b>Total Run Hour</b>	.

### 5.5.8 Fault Record Data


- ▶ Save Fault date When fault happens

<b>* Fault State #0/0</b>	Display Fault data. Max. 30(30/30)
<b>=&gt;Fault Data Empty</b>	


## 5.6 Interface

### 5.6.1 User1 (D-sub 37pin, Digital I/O, Analog I/O)

No.	Name	Description	Remark
7	ON	Enables output power	Digital/Input
14	OFF	Used for turning output power shut off	D/I
5	Regulation	LH : Current HL : Power HH : Voltage	D/I
6	Regulation		
11	AUX	Interrupt the interlock system	D/I
12	VACUUM	Interrupt the interlock system	D/I
13	WATER	Interrupt the interlock system	D/I
2	ON/OFF state	Indicates that output power is ON	Digital/Output
1	Limit	When the output reach the limit.	D/O
3	Setpoint	Indicates when output reach to set value	D/O
33	FAULT	Indicates when fault occurs	D/O
22	EOTL	Indicates target life is ended(N/A)	D/O
20	Protection	When it's happening protection.	D/O
21	ARC	Indicates when arc occurs	D/O
36	COM.D	Dedicated return for digital signal	
19	COM.D	Dedicated return for digital signal	
37	COM.D	Dedicated return for digital signal	
27	Reference	The output reference set(Analog/Input)	Analog/Input
25	Iout	The output current show(Analog/Output)	Analog/Output
31	Ref.out	The output reference show(A/O)	A/O
18	15V	15V	Nonisolated
9	G	25,31,23,24(Return G)	A/O
10	G	27(Return G)	A/I
23	Vout	The output voltage show(A/O)	A/O
24	Pout	The output power show(A/O)	A/O



User port(37Pin)



\* ON/OFF

		[14]OFF	
		Closed	Opened
[7]ON	Closed	OFF	ON
	Opened	OFF	X

\* Regulation Mode Selection

		[6]REG2	
		Closed	Opened
[5]REG1	Closed	X	Current
	Opened	Power	Voltage

Digital Input


Digital Output

Analog I/O

D-Sub 37 Pin

※ Example 1  
Power supply

Controller(PLC)



Digital Input

Digital Output

Analog I/O

D-Sub 25 Pin

Power On/Off


Regulation Mode

Interlock (N.C)

Analog Output Signal (0~10V)

Analog Input Signal (0~10V)

## 5.6.2 RS-232




&lt;9-Pin D female connector&gt;

Pin	Name	Description
2	RxD	Receive Data
3	TxD	Transmit Data
5	GND	Ground

D-Sub	No.	Command	Description	Range	Data Byte
RS-232 (TX)	1	Output ON	Output ON		1
	2	Output OFF	Output OFF		1
	3	Regulation	Output regulation		1
	4	Reference	Output level		2
	5	Detection time	Arc detection time		2
	6	Pause time	Arc pause time		2
	7	Arc voltage	Arc voltage level		2
	8	Arc current	Arc current level		2
	9	Soft arc level	Soft arc level		2
	10	Shutdown delay time	Shutdown delay time		2
	11	Shutdown Pause time	Shutdown Pause time		2
	12	Power limit			2
	13	Current limit			2
	14	Voltage limit			2
	15	Ramp time			2
	16	Ignition voltage			2
RS-232 (RX)	17	Output ON	Request data		1
	18	Output OFF			1
	19	Regulation			1
	20	Reference			2
	21	Detection time			2
	22	Pause time			2
	23	Arc voltage			2
	24	Arc current			2
	25	Soft arc level			2
	26	Shutdown delay time			2
	27	Shutdown Pause time			2
	28	Power limit			2
	29	Current limit			2
	30	Voltage limit			2
	31	Ramp time			2
	32	Ignition voltage			2


# Chapter 6. Maintenance

## 6.1 Error message or LED status in the front panel(For example).




[Stable state]

**Happening the input low voltage**




[Display Error message In VFD]



Lighting

Flashing

During 1 minute  
[180VAC>Input Volt>165VAC]



[Shut Down Output, <about 165VAC]

	Error message	Contents	LED	Remarks
1	AC Low Voltage Err! =>Chk cable or Sag	Input cable misconnection or Sag phenomenon Input Low Voltage		Fault LED after 1min.
2	AC Low Voltage Err! =>Chk cable, Interrut	Input cable misconnection or input Voltage interruption(less than 165VAC)		Fault LED after 1min.
3	AC OverVoltage Err =>Chk Input Voltage	Over input voltage(+10%)		Directly Fault LED, output off
4	AC Unbalance Err! =>Chk cable, terminal	Input cable misconnection or Unbalance phase		Fault LED after 1min.
5	Inv. Unbalance Err =>Chk Stack Fuse/cap	Inverter unbalance in the power, Broken the Fuse at the power stack, Broken the current sensor circuit.		Directly Fault LED, output off
6	Over Temperatur Err =>Chk 24V P/S or Fan	Overtemperature(more than 90℃), Ambient Temp. is above 40degree. Broken the 24V SMPS for Operating the fan in the power, a poor required region for cooling the power supply, Filled the Hole with dusty particle in the front panel.		Output off more than 92℃ on the heatsink in the power
7	Controller/SMPS Err =>Chk MCU & SMPS	SMPS breakdown or drop the control volt.(less than 4.5V)		Directly Fault LED, output off
8	Ignition Fail ! =>Chk GAS state, etc.	No the output current ( less than 100mA ) , No supply the gas(Ar etc. )		
9	Hard Arc State ! =>Chk Target(Chamb)	Output is short circuit. Happening the Arc discharge.		
10	Now, Stopped by External Signal Check Interlock Port ->Water, Door, Vacuum	Interlock signal by the User Port, Opening the door etc.		

## Chapter 6. Maintenance

---

### 6.2 General Troubleshooting

Symptoms	Probable Cause	Recommendations
Display(VFD) does not light	AC input power not connected.	Check rear panel input connector's connection and input power
	AC input circuit protector not turned on.	Turn the input circuit protector on
No output	Output power connector Interlock is open.	Check the interlock port
	The load is not connected	Make sure that the load is connected

